# **Engineering Physics Laboratory (Course Code : PHY119)**

### **Experiment - 3**

**AIM:** To determine the Hall voltage and Hall coefficient by using Hall effect.

# **Learning Objectives**

1. To understand new phenomenon called Hall effect.


2. Variation of Hall voltage with magnetic field keeping current through specimen fixed and vice-versa.


3. To calculate various parameters of the given material like number density, mobility etc.

# **LET US START**




# **HALL EFFECT**





# LORENTZ FORCE (Click)



$$F_B = Bqv$$
 $F_E = Eq$  but  $E = \frac{V_H}{d}$ 
 $F_E = \frac{V_H}{d}q$ 
So if  $F_B = F_E$ 

$$B \not q'v = \frac{V_H}{d}q'$$

#### Hall effect is a very useful phenomenon and helps to

✔ Determine the Type of Semiconductor

By knowing the direction of the Hall Voltage, one can determine that the given sample is whether n-type semiconductor or p-type semiconductor. This is because Hall coefficient is negative for n-type semiconductor while the same is positive in the case of p-type semiconductor.

Calculate the Carrier Concentration

The expressions for the carrier concentrations of electrons (n) and holes (p) in terms of Hall coefficient are given by

$$n=rac{1}{qR_H} \quad and \quad p=rac{1}{qR_H}$$


Determine the Mobility (Hall Mobility)

Mobility expression for the electrons ( $\mu_n$ ) and the holes ( $\mu_n$ ), expressed in terms of Hall coefficient is given by,

$$\mu_n = \sigma_n R_H$$
 and  $\mu_p = \sigma_p R_H$ 

# A video illustrating Hall effect and its applications

# Hall Effect



# **Check your understanding**

Q3.1: In the Hall Effect, the directions of electric field and magnetic field are parallel to each other.

The above statement is

a) True

b) False

Q3.2: Which of the following parameters can be found with Hall Effect?

- a) Polarity (n or p-type)
- b) Conductivity
- c) Carrier concentration
- d) All of these.

Q3.3: In the Hall Effect, the electric field is in x direction and the velocity is in y direction. What is the direction of the magnetic field?

- a) X
- b) Y
- c) Z
- d) XY plane

Q3.4: In Hall effect, the force responsible for the separation of charge carriers which results in Hall voltage is

- a) Coulomb force
- b) Gravitational force
- c) Lorentz force
- d) Nuclear force

Q3.5: In Hall Effect, the electric field applied is perpendicular to both current and magnetic field?


a) True

b) False

# Step by Step guide to perform the experiment in Virtual lab

Follow the slides below.

#### Type this link on the address bar or Click on this link: <a href="https://www.vlab.co.in/">https://www.vlab.co.in/</a>




#### **Electrical Engineering**


Electrical Engineering. Home » Broad Areas of Virtual Labs ...


#### Mechanical Engineering

Mechanical Systems and Signal Processing Lab. Reference ...

### Click on the simulator







# Activity Based Polling while the students perform the experiment in virtual lab

### A

**A3.1:** Measured value of the magnetic field when current of 3.5 amperes passes through the electromagnet is

- a) 0.5188 Tesla
- b) 34.507 Tesla
- c) 5.188 Tesla
- d) 0.34507 Tesla

### A

A3.2: Measured value of the Hall voltage for germanium sample, when a current of 2 mA passes through it and placed in perpendicular magnetic field of 0.4447 Tesla. Take thickness of the specimen to be 0.5 mm.

- a) 22.607 mV
- b) 34.507 mV
- c) 2.2607 mV
- d) 3.4507 mV

### A

A3.3. Calculate the carrier concentration for semiconductor (Ge) of thickness 0.3mm. (As per simulator)

- a) 3.22 X 10<sup>2</sup>0
- b) 4.55 X 10<sup>2</sup>0
- c) 6.55 X 10<sup>2</sup>0
- d) 2.46 X 10<sup>2</sup>0

Q3.4: Calculate manually the Hall Effect coefficient when number of electrons in a semiconductor is 10<sup>20</sup>.

a) 0.625

b) 0.0625

c) 6.25

d) 62.5