

Experiment Number

To find out the energy band gap of a semiconductor by four probe method.

Learning Objectives

- 1. To measure the resistivity of a semiconductor material using four probe method.**
- 2. To study the temperature variation of resistivity of a semiconductor material.**
- 3. To find out the energy band gap of a semiconductor.**


The student will also be able

- 1. To visualize the position of the four probes on the sample in the virtual lab environment.**
- 2. To select the range and values of different variables to conduct the experiment.**
- 3. To find out the values of the voltage across the sample, while passing a fixed amount of current, at different measuring temperature.**
- 4. To calculate resistivity of the sample under consideration from the simulator data.**
- 5. To understand the temperature variation of resistivity of a semiconductor sample by plotting suitable graph.**

Basic Understandings

Semiconductor


- ❖ Semiconductors are materials which have electrical conductivities lying between good conductors and insulators.
- ❖ Elemental semiconductors such as silicon germanium belongs to the Group IV of the periodic table.



Electronic configuration of Ge: $1s^2 2s^2 2p^6 3s^2 3p^6 3d^{10} 4s^2 4p^2$

Electronic configuration of Si : $1s^2 2s^2 2p^6 3s^2 3p^2$

- ❖ Natural pure form of a semiconductor is known as intrinsic semiconductor.
- ❖ Conductivity is mainly due to thermally generated charge carriers.
- ❖ Electron hole pair generation on breaking of a covalent bond.



Metals , Semiconductors, Insulators



Copper
(metal)




Germanium or Silicon
(semiconductor)



Wood
(insulator)

Resistivity ranges (approx.)
Conductors: 10^{-8} to 10^{-6} ohm-m
semiconductors: 10^{-5} to 10^4 ohm-m
Insulator: 10^7 to 10^8 ohm -m




Plastic (insulator)

Ceramic insulator



Energy band gap




□ The energy difference between the valence band and conduction band is called band gap.

□ In case of semiconductors the energy gap between filled valence band and empty conduction band is small compared to insulators but more as compared to conductors.

The band gap of semiconductor varies from 0.2 to 2.5 eV. For Germanium it is ~ 0.67 eV. whereas the bandgap of a typical insulator (diamond) 6 eV.

□ Due to small energy band gap between the valence band and conduction band ,the electrons of valence band can be thermally excited to the conduction band.

Metal, Semiconductor and Insulator



*Energy not to scale

Calculation of energy band gap of a semiconductor from the temperature variation of resistivity


The resistivity (ρ) of a semiconductor sample can be expressed as -

Where E_g is Band Gap in eV, k is Boltzmann constant $=8.617 \times 10^{-5} \text{ eVK}^{-1}$, T is absolute temperature in Kelvin

The constant A depends on carrier concentrations and mobility of the charge carriers (electrons and holes)

Taking natural logarithm on both side of equation (i)

(B is another Constant)



Or

So by plotting a graph between $\log \rho$ versus $1000/T$ we can find out the slope and hence the energy band gap of the semiconductor material.

Q1.1 : Which of the following statement(s) is (are) true about semiconductors:

- (A) there is a small energy gap between the valence band and conduction band**
- (B) valence band and conduction band overlap with each other.**
- (C) electrons of valence band can be thermally excited to the conduction band.**
- (D) both the options (A) and (C)**

Q1.2 : The display panel of a temperature sensor indicates 45°C . The corresponding temperature in Kelvin is

- (A) 228 K**
- (B) 273 K**
- (C) 308 K**
- (D) 318 K**

Check your understanding

Q

Where A is a constant, E_g is Band Gap in eV, k is the Boltzmann constant $=8.617 \times 10^{-5} \text{ eVK}^{-1}$, T is absolute temperature in Kelvin

Q1.4 : With increase in temperature, the conductivity ($\sigma=1/\rho$) of the semiconductor sample

- (A) decreases**
- (B) increases**
- (C) remains constant**
- (D) suddenly drops to zero**

Q1.5 : Unit of energy band gap is

- (A) Electron volt**
- (B) Coulomb**
- (C) Volt/meter**
- (D) Joule/second**

Step by Step guide to perform the experiment in Virtual lab

Type this link on the address bar or Click on this link : <https://www.vlab.co.in/>



www.vlab.co.in ▼

Virtual Labs

To provide remote-access to Labs in various disciplines of Science and Engineering. These **Virtual Labs** would cater to students at the undergraduate level, post ...

Results from vlab.co.in



Electronics & Communications

Reference Books. DIGITAL
DESIGN ? Third Edition , M ...

Physical Sciences

Physical Sciences. Home » Broad
Areas of Virtual Labs. Labs ...

Civil Engineering

Civil Engineering. Home » Broad
Areas of Virtual Labs. Labs ...

Computer Science ...

Reference Books. Fundamentals of
Data structures by Ellis ...

Electrical Engineering

Electrical Engineering. Home »
Broad Areas of Virtual Labs ...

Mechanical Engineering

Mechanical Systems and Signal
Processing Lab. Reference ...

This page will open. Scroll down the page end click on Physical sciences



An MHRD Govt of India Initiative

An Initiative of
Ministry of Human Resource Development
Under the National Mission on Education through **ICT**



HOME

ABOUT US

NEWSLETTER

NEW LAB DEVELOPMENT

BECOME NODAL CENTER

OUTREACH PORTAL

PARTICIPATING INSTITUTES

CONTACT US



OBJECTIVES

THE PHILOSOPHY

SALIENT FEATURES

Objectives

Scroll down the page end click on Physical sciences

Broad Areas of Virtual Labs

- ❏ Electronics & Communications
- ❏ Computer Science & Engineering
- ❏ Electrical Engineering
- ❏ Mechanical Engineering
- ❏ Chemical Engineering
- ❏ Biotechnology and Biomedical Engineering
- ❏ Civil Engineering
- ❏ Physical Sciences
- ❏ Chemical Sciences

Participating Institutes



IIT GUWAHATI



IIT DELHI



IIT BOMBAY



IIT KANPUR



IIIT
HYDERABAD



श्रद्धावान् लभते ज्ञानम्
AMRITA
VISHWA
VIDYAPEETHAM



IIT MADRAS



DAYALBAGH
EDUCATIONAL
INSTITUTE

Then click on - Solid state Physics Virtual Lab



An Initiative of
Ministry of Human Resource Development
Under the National Mission on Education through **ICT**

[HOME](#)[ABOUT US](#)[NEWSLETTER](#)[NEW LAB DEVELOPMENT](#)[BECOME NODAL CENTER](#)[OUTREACH PORTAL](#)[PARTICIPATING INSTITUTES](#)[CONTACT US](#)

Physical Sciences

[Home](#) » [Broad Areas of Virtual Labs](#)

Labs ready for use

Virtual Astrophysics Lab

[Reference Books](#) ▼ [Syllabus Mapping](#) ▼

IIT KANPUR

Molecular Interactions Lab

[Reference Books](#) ▼ [Syllabus Mapping](#) ▼

IIIT HYDERABAD

Advanced Analytical Chemistry Virtual Lab

[Reference Books](#) ▼ [Syllabus Mapping](#) ▼

AMRITA VISHWA
VIDYAPEETHAM

Solid State Physics Virtual Lab

[Reference Books](#) ▼ [Syllabus Mapping](#) ▼

AMRITA VISHWA
VIDYAPEETHAM


Announcements

* **4th edition of Virtual Labs Newsletter is released.** Please click [here](#) to download.

* Various projects/ICT initiatives of MHRD are available on the link given [here](#). Please click [here](#) for more




Then click on – Resistivity by Four probe Method



VALUE @ Amrita

Virtual Amrita Laboratories Universalizing Education



AMRITA
VISHWA VIDYAPEETHAM

[Home](#) [Project](#) [Workshop](#) [Nodal Centres](#) [News & Events](#) [Publications](#) [Survey](#) [Contact us](#) [Login](#)Google Custom Search you are here->[home](#)->[physical sciences](#)->[solid state physics virtual lab](#)

Characteristics of Zener diode

A Zener diode is a diode which allows current to flow in the forward direction in the same manner as an ideal diode, but will also permit it to flow in the reverse direction when the voltage is above a certain value known as the breakdown voltage



Characteristics of Thermistor

A thermistor is a type of resistor whose resistance strongly depends on temperature. A thermistor is a temperature-sensing element. The aim of experiment is to find its characteristics and temperature coefficient of resistance.



Resistivity by Four Probe Method

To determine the resistivity of semiconductors



B-H Curve

The lag or delay of a magnetic material known commonly as Magnetic Hysteresis. Hysteresis is the dependence of a system not only on its current environment but also on its past environment. This dependence arises because the system can be in more than one




Hall effect experiment:- Determination of charge carrier density


The production of transverse voltage across a current carrying conductor when placed in a perpendicular magnetic field, is called Hall effect. The voltage developed across the conductor is called Hall voltage.

19

Details of the experiment will be available to you . You may login also.

- Read the theory
- Procedure
- Complete the self evaluation to check your understanding
- Then click on the simulator








**VALUE @ Amrita**
Virtual Amrita Laboratories Universalizing Education

**AMRITA**
VISHWA VIDYAPEETHAM

Home Project Workshop Nodal Centres News & Events Publications Survey Contact us Login ENHANCED BY Google Search

you are here->home->physical sciences->solid state physics virtual lab->resistivity by four probe method

Resistivity by Four Probe Method

 Theory  Procedure  Self Evaluation  Simulator  Assignment  Reference  Feedback

AIM

To determine the resistivity of semiconductors by Four probe Method.

APPARATUS

The experimental set up consists of probe arrangement, sample , oven 0-200°C, constant current generator , oven power supply and digital panel meter(measuring voltage and current). Four probe apparatus is one of the standard and most widely used apparatus for the measurement of resistivity of semiconductors.

This method is employed when the sample is in the form of a thin wafer, such as a thin semiconductor material deposited on a substrate. The sample is millimeter in size and having a thickness w . It consists of four probe arranged linearly in a straight line at equal distance S from each other. A constant current is passed through the two probes and the potential drop V across the middle two probes is measured. An oven is provided with a heater to heat the sample so that behavior of the sample is studied with increase in temperature.






Fig:1

Fig:2

20

When Click on the simulator , this page will be visible

VALUE @ Amrita
Virtual Amrita Laboratories Universalizing Education

AMRITA
VISHWA VIDYAPEETHAM

Home Project Workshop Nodal Centres News & Events Publications Survey Contact us Login

ENHANCED BY Google

you are here->home->physical sciences->solid state physics virtual lab->resistivity by four probe method

Resistivity by Four Probe Method

Theory Procedure Self Evaluation Simulator Assignment Reference Feedback

Resistivity by Four Probe Method




**Then click here to
open the list of
variables**

**the list of variables
is available now.**

**But it covers some
portion of the oven and
you have to toggle the
show variables option
while performing the
experiment.**

Resistivity by Four Probe Method



Resistivity by Four Probe Method

VARIABLES

Select Material :

Germanium ▼

Range of Current :

20 mA ▼


Current (mA) : 1



Oven

☐ Cross Section

Range of Oven :



Copyright © Amrita University 2009 - 2015

Resistivity by Four Probe Method



Theory



Procedure



Self Evaluation



Simulator



Assignment



Reference



Feedback

Resistivity by Four Probe Method

VARIABLES

Select Material :

Germanium ▼

Range of Current :

20 mA ▼


Current (mA) : 1



Oven

☐ Cross Section


Range of Oven :



Copyright © Amrita University 2009 - 2015

Click here to zoom

When Click on the simulator , this page will open



Copyright © Amrita University 2009 - 2015

the list of
variables is
available
now
conveniently

?

VARIABLES

Select Material :
Germanium

Range of Current :
20 mA

Current (mA) : 1

120

Oven

☐ Cross Section

Range of Oven :
x1

SETMEASURE

RUNWAIT

Temperature (°C) : 25




2595

Range of Voltmeter :
10 V

RESET

MEASUREMENTS

Click on the cross section checkbox to see the probes



VARIABLES

Select Material :
Germanium

Range of Current :
20 mA

Current (mA) : 1

1

20

Oven

☒ Cross Section

Range of Oven :
x1

SET

MEASURE

RUN

WAIT

Temperature (°C) : 25


25

95

Range of Voltmeter :
10 V

RESET

MEASUREMENTS



VARIABLES

Select Material :

Germanium ▼

Range of Current :

20 mA ▼

Current (mA) : 3.0

1 20

Oven

☐ Cross Section

Range of Oven :

x1 ▼

SET

MEASURE

RUN

WAIT

Temperature (°C) : 25

25 95

Range of Voltmeter :

100 mV ▼

RESET

MEASUREMENTS

Selection of the variables

Select the material from the drop down button. Either Silicon or Germanium. Select Germanium here. Then Select the range of current to 20 mA


Set the current to say 3 mA

Set the range of the oven to x1 or 10 (as required)



Set the range of the voltmeter to 100 mV from the drop down options

If you want to change the input values, only then click 'Reset' otherwise you are good to start the experiment.

Next you have to set the temperature of the oven and run it.



Note: Convert the temperature from degree centigrade to Kelvin. Say if we want to perform the experiment from 25 °C to 70 °C. with step of 5 °C . Then write the temperature values in the worksheet column accordingly in Kelvin (adding 273 to °C).



VARIABLES

Select Material :
Germanium ▼

Range of Current :
20 mA ▼

Current (mA) : 3.0

1 20

Oven

☐ Cross Section

Range of Oven :
x1 ▼

SET

MEASURE

RUN

WAIT

Temperature (°C) : 70

25 95

Range of Voltmeter :
100 mV ▼

RESET

MEASUREMENTS

Then Click on “Set” and set the temperature (say to 70 °C) by sliding the temperature bar.

Then Click on “Run”

Oven temperature will now increase. Check the oven display panel and click “wait” to note down the millivoltmeter readings (in the worksheet) at each 5°C (or 5K) interval up to 70 °C (i.e. 343 K)

Now first note down the millivoltmeter reading at room temperature (25 °C) in the worksheet. Then for other temperature values. Don't forget to run again after noting down the readings.

Worksheet

Current I=mA

Correction factor, $F(W/S) = \dots \mathbf{5.89} \dots$

$$\rho = \rho_0 / F(W/S) = \dots\dots\dots$$

Temperature (°C)	Temperature (K)	Voltage across inner probe (mV)	1000/T	Considering the correction factor (ρ) unit	logρ
----------------------	---------------------	---------------------------------------	--------	--	------

N.B: Take care about the unit.

Sample Data taken from the virtual lab

Table 1 (temperature range 25 to 70 C)

Current I set at 3 mA


A(X1)	G1(Y1)	B(Y1)	C(X2)	D(Y2)	E(Y2)	F(Y2)
Temperature (C)	Temperature (K)	Voltage accross inner probe (mV)	1000/T	Resistivity (without correction factor)	Actual Resistivity (considering the correction factor)	log(actual resistivity)
25	298	87.24	3.3557	36.52448	6.2011	0.79247
30	303	84.65	3.30033	35.44013	6.017	0.77938
35	308	82.22	3.24675	34.42277	5.84427	0.76673
40	313	79.94	3.19489	33.46821	5.68221	0.75452
45	318	77.78	3.14465	32.56389	5.52867	0.74262
50	323	75.75	3.09598	31.714	5.38438	0.73114
55	328	73.83	3.04878	30.91016	5.2479	0.71999
60	333	72.01	3.003	30.14819	5.11854	0.70915
65	338	70.3	2.95858	29.4227	4.99699	0.69871
70	343	68.67	2.91545	28.74984	4.88113	0.68852

Table 2 Table 1 (temperature range 25 to 200 C) over range set as x10


Temperature (C)	Temperature (K)	Voltage accross inner probe (mV)	1000/T	Resistivity (without correction factor)	Actual Resistivity (considering the correction factor)	log(actual resistivity)
25	298	87.24	3.3557	36.52448	6.2011	0.79247
50	323	75.75	3.09598	31.714	5.38438	0.73114
75	348	67.12	2.87356	28.10091	4.77095	0.67861
100	373	60.45	2.68097	25.3084	4.29684	0.63315
125	398	55.16	2.51256	23.09365	3.92082	0.59338
150	423	50.88	2.36407	21.30176	3.6166	0.5583
175	448	47.86	2.23214	19.82805	3.36639	0.52716
200	473	44.41	2.11416	18.59299	3.1567	0.49923

Plot the graph between $1000/T$ and $\log \rho$.

*The students can plot the graph in normal graph paper (or in MS-Excel or any graph plotting software)




From table 1 (zoomed)



From table 2

How to calculate energy Band gap from the plotted graph?

Plot the graph between $1000/T$ (along x-axis) and $\log_{10}\rho$ (along y-axis). Find the slope and then use the following formula





A1.1. In this four probe experiment, a Germanium crystal is kept inside the oven. What is the voltage drop at 25 °C when current $1\mu\text{A}$ is passing through outer two probes on the sample

- (A) 29.08 V
- (B) 29.08 mV
- (C) The outer two probes are not for passing current
- (D) Can not be determined with this set up

A1.2 : In order to run the oven and take readings from the voltmeter display panel which of the following is the correct order -

- (A) Set temperature > Set the range of the voltmeter > wait > Measure
- (B) Set temperature > Set the range of the voltmeter > Run > wait > Run (again)
- (C) Set the range of the voltmeter > Run > wait > Set temperature
- (D) No need to it manually, data will be automatically collected

A1.3 : The maximum range of the voltmeter that can be set up in this virtual lab set up is

- (A) 1 mV**
- (B) 100 mV**
- (C) 10 V**
- (D) 100 V**

A1.4 : In this experiment, let's consider the case when 3 mA of current is passing through the Ge crystal at 25 °C. The resistivity of the sample (as shown by the simulator) is –

- (A) 87.24 ohm cm
- (B) 87.24 ohm⁻¹ cm⁻¹
- (C) 6.2011 ohm cm
- (D) 6.2011 ohm⁻¹ cm⁻¹

Check the answer before giving in class or modify question

A1.5 : In the Four probe experiment, when the temperature of the Ge crystal is increased from 55 °C to 65 °C the change in resistivity (for $I = 3 \text{ mA}$) is

- (A) 0.2512 ohm cm**
- (B) 5.2749 ohm cm**
- (C) 5.0204 ohm cm**
- (D) None of the above**

Check the answer before giving in class or modify question

Experimental set up in our lab

Apparatus: Probe arrangement, Four probes set up with digital millivoltmeter and constant current generator, Sample crystal (Germanium), Oven

